

# **Software update procedure – Speed Quad**

## **03.10.2014**



**ATTENTION!** *The tablet must be fully charged when initializing the procedure.*




**ATTENTION!** *Please do not stop under any circumstance the update operation.*

*The software update is an operation which is realised on own responsibility by following the steps below.*

To update the software version of the **Allview Speed Quad** tablet it is necessary to follow the next steps:

1. Download the “**Update\_SpeedQuad\_03.10.2014.zip**” archive on a desktop PC or a laptop.
2. Copy the “**Update\_SpeedQuad\_03.10.2014.zip**” archive on the internal storage or on a microSD card.
3. Start the tablet and open the **Update** app from the app menu:



4. Press the app's option "**Local Update**".



## PAD UPDATE GUIDE

### PAD Description :

PAD based on the Android platform

### PAD Update :

Two update modes are supported at present:

- 1) Local Update
- 2) Online Update

### Update DOs and DON'Ts :


- 1) Do not disconnect the power during the update;
- 2) If you cannot enter the system due to errors during the update, reset the system through the Recovery Mode;
- 3) If you still cannot enter the system through Recovery Mode, please contact us.

Online  
update


Local  
update



5. Select the update file from the internal storage or from the microSD:  
“Update\_SpeedQuad\_03.10.2014.zip”.



6. A message will be displayed on the phone's screen that will inform you about this update.



7. Select **Update**. The tablet will reboot and it will start automatically the update procedure.

8. The update procedure will be pointed by a status bar.



9. After the update process is finished, the tablet will reboot.



We recommend **Factory Reset** after the update to avoid some errors.



**ATTENTION!** The tablet's factory reset will completely delete your personal information and all the apps installed on the tablet.