



The update procedure through OTA – Allview P6 Energy Lite / Android 6.0 / 29.12.2016



The software update advantages are:

- ✓ *software stability improvement;*
- ✓ *fixing some minor bugs.*



ATTENTION! *The phone must be fully charged when initializing the procedure.*




ATTENTION! *Please do not stop the update operation under any circumstance.*

The software update is an operation which is made on own responsibility by following the steps below.




To update the software version of the *Allview P6 Energy Lite* smartphone, follow the next steps:

1. Turn on the phone and connect it to a wireless network.
2. Make sure you have the SD Card inserted in the phone and selected as the default writing location.




3. Open the **"System updates"** app from the apps menu:




4. In the “**System Update**” app check the new software version (**P6_Energy_Lite_SV18.0**).
Click **Download**:




5. Please wait for the full software download in the phone's storage (micro SD card).




6. After the full software download, a message will be displayed on the phone's screen that will inform you about this update:



7. Select **Done**. The phone will reboot and the update procedure will automatically start.



8. After finishing the update process, the phone will reboot itself.



9. On the phone's screen the following message will be displayed: ***“Android is upgrading”***.

The update file downloaded in the phone's storage (micro SD card) will be deleted automatically after the termination of the update process.



ATTENTION! For optimal running we recommend to reset your device to factory settings after installing the update!