



The update procedure through OTA – Allview P6 Energy Lite / Android 6.0 / 07.02.2017



The software update advantages are:

- ✓ *software stability improvement;*
- ✓ *fixing some minor bugs.*



ATTENTION! *The phone must be fully charged when initializing the procedure.*



ATTENTION! *Please do not stop under any circumstance the update operation.
The software update is an operation made on own responsibility by following the steps below.*




ATTENTION! *The update works from versions SV16, SV17, respectively SV18.*




To update the software version of the *Allview P6 Energy Lite* smartphone please follow the next steps:


1. Turn on the phone and connect it to a wireless network.
2. Make sure the SD Card is inserted in the device and is selected as the default location writing.




3. Open the **"System updates"** app from the apps menu:




4. In “**System Update**” app check new software version (**P6_Energy_Lite_SV20.0**). Click Download.




5. Please wait for the full software download in the phone's storage (micro SD card).




6. After the full software download, a message will be displayed on the phone's screen that will inform you about this update:



7. Select **Done**. The phone will reboot and the update procedure will automatically start.



8. After finishing the update process, the phone will reboot itself.



9. **“Android is upgrading”** will be displayed on the phone's screen.

The update file downloaded in the phone's storage (micro SD card) will be deleted automatically after the termination of the update process.



ATTENTION! For optimal running of the device, we recommend factory reset after installing the update!