

SW update procedure – X1 Soul



The advantages for software update are

- stability improvement
- download/upload speed- WiFi improvement



ATTENTION! *The phone must be fully charged when initializing the procedure.*




ATTENTION! *Please do not stop under any circumstance the update operation.*


The software update is an operation which is realised on its own responsibility by following the steps below.

To update the software version of the Allview X1 Soul smartphone it is necessary to follow the next steps:


1. Download the **“Update_X1_Soul_12.12.2014.zip”** archive on a desktop PC or a laptop.
2. Copy the **“Update_X1_Soul_12.12.2014.zip”** archive in the internal storage.
3. Start the phone and open the **System Update** app from the app menu:




4. Press Menu. Check the "***Select updates from nternal storage***" option.




5. Select the update file from the internal storage as it follows: **FILE -> Internal Storage -> "Update_X1_Soul_12.12.2014.zip"**.




6. A message will be displayed on the phone's screen that will inform you about this update.



7. Select **Update**. The phone will reboot and it will start automatically the update procedure.



8. After the finishing of the update process, the phone will reboot itself.



9. On the phone's screen this message will be displayed: ***“Android is upgrading”***.



The update file ***Update_X1_Soul_12.12.2014.zip*** downloaded in the internal storage will be deleted automatically after the end of the update process.



We recommend factory Reset after the update, to avoid some errors.



ATTENTION! *The phone's factory reset will completely delete all personal information and the apps installed in the phone.*